
# Pavo 80 IP65 Downlight

# Installation / Maintenance Instructions



### **Precautions and Warnings**

•Read all instructions carefully, the safety of this product is only guaranteed if the instructions are followed, retain these instructions for future use.

•Turn off the power suppler before installation and maintenance.

•Installation must be carried out be a trained professional in accordance with all National electrical' codes and regulations.

•To avoid the risk of fire and overheating, make sure all connection, including those made by others, are correct and secure.

•Do not pinch or apply excessive tension on the electrical wires. Damage due to improper handling and installation will void the warranty.

•If there is any damage to the product or the cable, the product must be returned to the retailer or manufacturer.






#### Luminaire Details

230V AC 50Hz
IP65
45°C

Fixing Method:	Plaster in
Bezel Diameter:	80mm
Recess Depth:	92mm
Ceiling cutout	95mm
Ceiling Thickness range:	1-22mm

<b>Light Forms</b> UK Head Office	LightForms.com	8 Richfield Avenue Reading RG1 8EQ	e T +44 (0)20 8571 3785 E London@ LightForms.com	
Registered in England & Wales No. 6750892		ISO 14001 Environm	Quality Management Environmental Management Occupational Health & Safety Management	


## **Tools for Installation**



# Pavo 80 IP65 Downlight


## Installation / Maintenance Instructions

### •Wiring Diagram for Non Dimmable Driver



#### •Wiring Diagram for Phase Cut Driver

**LIGHTFORMS** 



### • Wiring Diagram for DALI dimming Driver

